





2 in 1 booster seat **user guide**



IMPORTANT. KEEP FOR FUTURE REFERENCE

introduction

This two height booster seat is designed to be fitted to a suitable chair*, to raise the height of your child when sat at a table.


WARNING: It is recommended that the booster seat be used in the upright position only by children capable of sitting upright unassisted (around six to nine months). The product is suitable for children up to approximately 4 years.

When removed from the booster, the base can also be used as a step stool (weight limit 40 kg maximum).

* Refer to page 6 safety notes for information on suitable types of chairs.


parts checklist

fig 1



upper seat & harness

fig 2



lower seat / step stool

fig 3




securing strap

preparation for use

the securing strap


fig 4



1. Disengage the buckle of the securing strap by squeezing the fastener prongs and pulling apart.

fixing the seat to the base

fig 5




Place the upper seat onto the base as shown, and press down firmly.

Tip: Assembly will be eased by firstly aligning the front edge of the seat and front edge of the base before fixing the two parts together.

preparation for use

fixing the seat to the base


fig 6



Ensure that the upper seat is securely engaged with the base. Firm clicks will be heard from both sides of the booster seat once product is secured.

fixing to the chair


fig 7



Position the booster on the chair*, wrap the securing strap underneath, and fasten the buckle.

* Refer to page 6 safety notes for information on suitable types of chairs.

fig 8




Tighten the securing strap by pulling on the free end to remove any slack. Always check that it is secure and stable before placing your child in the seat.

On cushioned chairs, it may be necessary to further tighten the strap once your child is in the seat.


the harness

fig 9




To fasten
Insert both fasteners securely
into their respective clasps

fig 10



Adjust the waist strap length by
pulling on the free end to remove
unwanted slack


fig 11



To release
Squeeze the fastener prongs and
pull apart.
Your child should be securely
harnessed at all times and should
never be left unattended, even for
short periods.

adjusting the height

fig 12



The height of the booster can be adjusted for taller & older children by removing the base.


Release the clips at both sides of the seat and lift the upper seat off the base.

The upper seat can then be used on a seat by securing as described on page 3.

Tip: Removal of the upper seat will be eased by releasing one clip before the other.

adjusting the height

fig 13



The base of the booster can be used as a step stool simply by turning it over once removed from the booster.

Ensure the step stool is only used on a level, stable, non-slip surface.


The weight limit for the step stool is 40 kg max.

care of your product

- The booster can be cleaned by sponging with warm water and a mild detergent. A mild disinfectant may be used.
- Stubborn marks may be removed with a non-abrasive cream cleaner. Never clean with abrasive, ammonia based, bleach based or spirit type cleaners.
- Periodically check for damage, including internally, and discontinue use if any part is damaged or broken.

safety notes

fig 14



The recommended type of chair is as shown left, with four legs, a high backrest, and firm seat.

If the chair has a cushioned seat, check the securing strap periodically to ensure it has not loosened.

Do not use the booster on a table top, stool, swivel chair, folding chair or any other type of chair to which the booster cannot be firmly secured.

- **WARNING:** Prevent serious injury or death from falls or sliding out:
- The booster must be fully secured to the seat before placing a child inside.
- Always secure the child in the restraint until the child is able to get in and out of the booster seat without help (about 2½ years old)
- When using the booster at a table, ensure the child cannot push against the table or another chair, and tip the booster and chair over.
- Keep away from trailing cords flexes, electric irons, ornaments and other such hazards.
- Do not use close to any source of heat.
- Never use the booster in a vehicle as a car seat.
- Do not move the booster or chair with the child inside.
- Do not use if any part is broken, damaged or missing.
- If the booster is used by someone unfamiliar with it e.g. grandparents always show them how it is used.
- Never leave your child unattended, even for the shortest time.