


mothercare



booster seat  
& step stool

user guide

Important! Keep for  
future reference

This two height booster seat allows your child to sit with you whenever using a table, by securing the booster on a suitable chair\*.

Suitable for children who can sit unaided (around six to nine months) to around 4 years.

When removed from the booster, the base can also be used as a step stool (weight limit 50 kg maximum).

\* Refer to section 6, safety notes for information on suitable types of chairs.

## diagram



## description


upper seat & harness

lower seat / step stool

securing strap

## the securing strap


1



With the upper seat upside down, pass the ends of the securing strap through the slots at the sides as shown.


## fixing the seat to the base

2



Place the upper seat onto the base as shown, and press down firmly to engage the clips at the sides of the seat (see diagram 3).

3



Ensure that the side clips have securely engaged.

## fixing to the chair


4



Position the booster on the chair\*, wrap the securing strap underneath, and fasten the buckle.

\* Refer to section 6, safety notes for information on suitable types of chairs.


5




Tighten the securing strap underneath by pulling on the end of the strap to remove any slack.

Always check that the booster is secure and stable before putting your child in.


## the harness



To fasten  
Pass one end of the waist strap through the loop on the crutch strap and insert the fastener securely into the clasp.




Adjust the waist strap length with part A.



To release  
Squeeze the fastener prongs and pull apart.

Your child should be securely harnessed at all times and should never be left unattended, even for short periods.

## adjusting the height




The height of the booster can be adjusted for taller & older children by removing the base.

Release the clips at both sides of the seat and lift the upper seat off the base.

The booster can then be used on a seat by securing as described on page 3.

## the step stool




The base of the booster can be used as a step stool simply by turning it over once removed from the booster.

Ensure the step stool is only used on a level, stable, non-slip surface.

The weight limit for the step stool is 50 kg max.

- The booster can be cleaned by sponging with warm water and a mild detergent. A mild disinfectant may be used.
- Stubborn marks may be removed with a non-abrasive cream cleaner. Never clean with abrasive, ammonia based, bleach based or spirit type cleaners.
- Periodically check for damage, including internally, and discontinue use if any part is damaged or broken.



The recommended type of chair is as shown left, with four legs, a high backrest, and firm seat. If the chair has a cushioned seat, check the securing strap periodically to ensure it has not loosened.

Do not use the booster on a table top, stool, swivel chair, folding chair or any other type of chair that the booster cannot be firmly secured to.

- **WARNING! YOUR CHILD'S SAFETY IS YOUR RESPONSIBILITY.**
- The booster must be fully secured on the seat before placing a child inside.
- Ensure the harness is correctly fitted and adjusted at all times.
- When using the booster at a table, ensure the child cannot push against the table or another chair, and tip the booster and chair over.
- Keep away from trailing cords flexes, electric irons, ornaments and other such hazards.
- Do not use close to any source of heat.
- Never use the booster in a vehicle as a car seat.
- Do not move the booster or chair with the child inside.
- Do not use if any part is broken, damaged or missing.
- If the booster is used by someone unfamiliar with it e.g. grandparents always show them how it is used.
- Never leave your child unattended, even for the shortest time.