

mothercare



folding booster seat

user guide

Important! Keep for
future reference

This two height booster seat allows your child to sit with you whenever using a table, by securing the booster on a suitable chair*, and when not in use, can be folded compactly for storage.

Suitable for children who can sit unaided (around six to nine months) to around 4 years.

* Refer to section 7, safety notes for information on suitable types of chairs.

diagram



description


booster frame with harness

reversible seat with
rear fixing strap

securing strap


tray

1



Swing the side panels outwards to make the side inside slots accessible.


2



Note that either surface of the seat, A or B can be used uppermost, to provide height adjustment.


Slide the guides at the sides of the seat into the slots in the booster frame.

3




Before pushing the seat fully into place, pass both rear fixing straps through the slots in the backrest.

4



Locate the studs at each side of the seat in the keyhole shaped sockets on the side panels, then ...


5



... press the seat firmly downwards until the studs click securely into place.

Check they are secure by pulling upwards on the front edge of the seat.


6



Feed the end of the crutch strap right through the slot in the seat, and check it is secure by pulling upwards on it.

Note: If the seat is used with the other surface uppermost, the crutch strap can be removed and passed through from the opposite side. See "strap removal" in the "care of your product" section.

7




Position the booster on the chair*, wrap the securing strap underneath, and fasten the buckle.

Tighten the securing strap by pulling on the end of the strap to remove any slack.

* Refer to section 7, safety notes for information on suitable types of chairs.

8




To avoid damage to the chair or buckle, both ends of the rear securing strap are adjustable so the buckle position can be positioned away from the corners of the chair.

Tighten the securing strap by pulling on the end of the strap to remove any slack.

Always check that the booster is secure and stable before putting your child in.

harness

1




To fasten the harness

Insert both fasteners securely into the clasp.

Adjust each strap length with buckles A.

2



To release the harness

Press the fastener prongs and pull apart.

Your child should be securely harnessed at all times and should never be left unattended, even for short periods.

tray


3



The booster can be used with or without its tray.

To use, slide the tray into the grooves in the side panels.

4



The position of the tray can be adjusted by releasing the side clips, moving to the desired position, and releasing.

Always check the tray is secure before use.


folding

1




Press and hold the button on the outside of each side panel, and ...

2




lift the studs at the sides of the seat out of the keyhole shaped slots in the side panels.

3




Swing the side panels outwards.

4




Pull the front of the seat forwards slightly.

5



Lift the seat so it rests against the backrest and swing the side panels inwards.

strap removal




The crutch strap can be removed to reverse the seat, and the harness straps can be removed for washing.

To remove the harness straps, pinch the ends of the straps to flatten them, and pass them through the slots in the booster.

The straps can be machine washed at 40 degrees centigrade.

When re-fitting, ensure the ends open out again so they cannot accidentally pull through the slots.

- The booster can be cleaned by sponging with warm water and a mild detergent. A mild disinfectant may be used.
- Stubborn marks may be removed with a non-abrasive cream cleaner. Never clean with abrasive, ammonia based, bleach based or spirit type cleaners.
- Periodically check for damage, including internally, and discontinue use if any part is damaged or broken.



The recommended type of chair is as shown left, with four legs, a high backrest, and firm seat. If the chair has a cushioned seat, check the securing strap periodically to ensure it has not loosened.

Do not use the booster on a table top, stool, swivel chair, folding chair or any other type of chair that the booster cannot be firmly secured to.

- **WARNING! YOUR CHILD'S SAFETY IS YOUR RESPONSIBILITY.**
- The booster must be fully secured on the seat before placing a child inside.
- Ensure the harness is correctly fitted and adjusted at all times.
- When using the booster at a table, ensure the child cannot push against the table or another chair, and tip the booster and chair over.
- Keep away from trailing cords flexes, electric irons, ornaments and other such hazards.
- Do not use close to any source of heat.
- Never use the booster in a vehicle as a car seat.
- Do not move the booster or chair with the child inside.
- Do not use if any part is broken, damaged or missing.
- If the booster is used by someone unfamiliar with it e.g. grandparents always show them how it is used.
- Never leave your child unattended, even for the shortest time.