



TREKABOUT CARRIER

User Guide

IMPORTANT
KEEP FOR
FUTURE REFERENCE

1


Introduction

Your Trekabout carrier is suitable for children who can sit up unaided (from around 6 months) to 18 kg in weight.


This deluxe carrier features a large zipped pocket for baby accessories, a play / change mat, a detachable rucksack, a detachable canopy for weather protection, and a weathershield.

2

Parts check list




Back Carrier




Weathershield




Canopy




Play / Change mat




Open the zipped compartment at the back and unfold the stand as shown.




Push both knobs forward to engage the spring button.



You will hear a "click" when each knob is fully engaged.




Place the stand into the pocket as shown.



Zip up the compartment.

Harness




TO ATTACH THE HARNESS

Insert fastener securely into the clasp.

Adjust shoulder strap length with buckles A.

The shoulder straps can be unclipped to help get your child in and out.

Adjust waist strap by pulling the free ends of straps.




TO UNDO THE HARNESS


Squeeze the prongs together to release the harness.

Your child should always be harnessed in and should never be left unattended even for short periods.


Placing your child in the carrier



Release the harness and place your child in the carrier, gently guiding their legs through the side openings.



Adjust the seat height by pulling on the strap as shown, and the front - back depth by adjusting the straps at the sides of the child.



Fasten and adjust the safety harness. It should be secure, but not too tight. Adjust the shoulder straps to suit your child's size. It is recommended that there should be just enough room to insert two fingers between the shoulder straps and your child's chest.

Putting the carrier on your back

IMPORTANT

It is advisable to seek assistance from another adult when putting the back carrier on.



Place the back carrier on your back, slide each of your arms into and through the shoulder straps. Make sure the backpack is sitting comfortably. Pull the two ends of the chest strap together and secure the buckle.



Pull the two ends of the waist strap to the front and secure the buckle. Adjust the belt if necessary. It should fit securely but not too tightly.




Adjust the fit of the shoulder straps by pulling the main straps at the bottom and / or the short straps at the top. The straps should fit securely but not too tightly.



Fasten the chest strap loosely, adjust its position and tighten.

Canopy and weathershield




Insert the canopy frame ends into the fabric "tunnels" on the insides of the backrest, and attach the velcro straps to secure.



If necessary, put the weathershield over the canopy and fasten the velcro tabs at the front. When fully dry, the weathershield can be stored in the back of the canpy.

Change / Play mat




The mat is stored inside the zipped compartment at the back of the carrier.

Removing the carrier from your back



Release the waist strap.



Release the chest strap.
Carefully lift the back carrier off and place on the floor.
Avoid swinging the backpack around too abruptly.

6

Care of your product

- To clean the seat, wipe the fabric with a damp cloth using warm water and mild detergent only. Allow to air dry.
- To clean the frame, wipe the metal surface with a damp cloth using warm water only. Dry completely using a soft cloth.
- To dry the carrier, always open the stand to allow air to circulate all around the fabric.
- Clean the surfaces of the carrier only. Do not immerse the carrier in water.
- Do not use strong detergents, abrasive or ammonia based cleaners.
- Inspect the carrier at regular intervals for wear and tear.
- Store the carrier in a dry place.
Use a non abrasive cleaning fluid and a soft cloth, to avoid scratches.

7

Safety notes

- Don't let children play with the carrier.
- Ensure your child wears the harness, correctly fitted and adjusted at all times.
- Ensure children are clear of moving parts before making adjustments.
Overloading, incorrect folding and the use of non-approved accessories may damage or break this carrier.
- Do not use your carrier in a manner for which it is not designed.
Don't let children play with the carrier.
- Only use the carrier for walking. Do not use it for ANY other activity which may injure your baby (such as cycling).